


Technical Systems

MARKET LEADER IN
FEED CONVEYING



Auger Coil Lifter

SPECIFICATIONS:

- Handle auger coils of up to 500kg by lifting pallets and re-allocate to another area
- Fork entry gap is 140mm x 60mm

PROCEDURE:

1. Ensure that the coil lifter is properly inserted into 1 fork of the forklift.
2. Attach the coil lifter properly to the forklift ensuring that the coil lifter will not slide off the fork.
3. Ensure proper attachment (under coil) by spreading the 3 hooks evenly on the coil.
4. Ensure that the coil is horizontal and stable before lifting.

ADVANTAGES:

- Saves time
- Improves staff safety
- No damage to auger coils

Contact us:

Tel nr: +27 21 949 9191
info@technicalsys.com
www.technicalsys.com
Cape Town, South Africa

© 2015 Copyright subsists in this document.
Any unauthorised performance of restricted acts (as defined in the Copyright Act, 98 of 1978) in respect of this document, including reproduction, publication or adaptation thereof, constitutes infringement of the copyright and may be liable to civil and/or criminal prosecution.